


## IBM i Support Roadmap



Support for IBM i 7.3 ended on September 30th, 2023.

Image Source: IBM

## Supported IBM i OS on IBM Power

Servers	IBM i 6.1 <sub>1</sub>	IBM i 7.1 <sub>1</sub>	IBM i 7.2 <sub>1</sub>	IBM i 7.3	IBM i 7.4	IBM i 7.5
<b>Power10</b> E1080, S1014, S1022s/S1022/L1022 (VIOS only), S1022s 2x4-core, S1024/L1024				✓	✓	✓
<b>Power9</b> S914, S922 (VIOS only), H922 (VIOS only), S924, H924, E980, S922 Entry (single native I/O partition only)		✓ <sub>4</sub>	✓	✓	✓	✓
<b>Power8</b> S814, S822 (VIOS only), S824, E870, E870C, E880, E880C S812 (no IBM i 7.1, native I/O only)		✓	✓	✓	✓	
<b>Power7/7+</b> 710, 720, 730, 740, 750 (VIOS only), 760 (VIOS only), 770, 780, 795	✓	✓	✓	✓		
<b>Power7 BladeCenter</b> PS700/701/702/703/704 (all VIOS only)	✓	✓	✓			
<b>Power7/7+ Flex</b> p260/270/460 (all VIOS only)	✓	✓	✓			
<b>POWER6+</b> 520, 550, 560, 570, JS23/43 (VIOS only)	✓	✓	✓ <sub>3</sub>			
<b>POWER6</b> 520, 550, 570, 595, JS12/22 (VIOS only)	✓	✓				
<b>POWER5/5+</b> 515, 520, 525, 550, 570, 595	✓	✓				
<b>800, 810, 825, 870, 890</b>	✓					

1 - IBM i 6.1, 7.1, 7.2: refer to IBM i Release Lifecycle for extended support information

<https://www.ibm.com/support/pages/node/6023368>

2 - Virtual client only

3 - no IOP or HSL support

4 - Available on selected S922 and E980 models only